

Microprocessor Power Supply Adjustment

- Turn off Power
- Loosen back cover
- Power Supply is located on inside of back cover on left side
- Right Side of power supply has 6 pin connector.
- For reference purposes, pin number 2 has no wire in it
- Turn Meter on DC volts
- Put Plus lead on Pin number 3
- Put Ground on Pin number 5
- Turn power back on
- Read DC Voltage
- Locate round trim Pot near Pin number 6
- Increase Voltage by .1 (One tenth) Volt DC by Turning Pot
- Turn Power Off and then Back On and see if all the 888's Clear
- Attach back cover